

Guide de lancement rapide de votre Microphone sans-fil

speechi

Référence : SPE-AOC027TL

Description

- ① Port d'alimentation
- ② Bouton d'appairage
- ③ Allumer / Éteindre
- ④ Port USB-C
- ⑤ Réinitialisation
- ⑥ Indicateur de charge
- ⑦ Indicateur de status
- ⑧ Couper le micro
- ⑨ Volume -
- ⑩ Volume +
- ⑪ Couper le son
- ⑫ Bouton d'appairage

1 Charger votre équipement

Charger votre équipement sur secteur via le port d'alimentation.①

2 Appairer un équipement avec sa clé USB

Allumer votre enceinte et appuyer sur le bouton d'appairage ② pendant 2 secondes.

Brancher votre récepteur USB à votre matériel et appuyez sur le bouton d'appairage.⑫

3 Appairer des équipements¹ en cascade (optionnel)

Allumer vos enceintes et appuyer sur le bouton d'appairage ② pendant 2 secondes.

Brancher votre récepteur USB à votre matériel et appuyez sur le bouton d'appairage.⑫

4 Sélectionner vos périphériques son et micro

Définir vos paramètres audio

Sortie son

- Haut-parleur C027 DONGLE
- Haut-parleur Realtek
- Haut-parleur Sharing Device

Entrée micro

- Micro C027 DONGLE
- Micro Realtek
- Micro Sharing Device

¹Jusqu'à 3 équipements maximum

Support et ressources : speechi.com/support-micros-visioconference
Email : support@speechi.com

Quick start guide Wireless speakerphone



Reference: SPE-AOC027TL

Description

- ① AC PORT
- ② Pairing button
- ③ Power button
- ④ USB-C Port
- ⑤ Reset
- ⑥ Battery indicator
- ⑦ Status indicator
- ⑧ Mute micro
- ⑨ Volume down
- ⑩ Volume up
- ⑪ Mute audio
- ⑫ Pairing button

1 Charge your speakerphone.

Plug your equipment into a power outlet via the power port. ①

2 Pairing your device with USB Dongle

Turn on your speaker and press the pairing button ② for 2 seconds.

Plug your USB receiver into your device and press the pairing button. ⑫

3 Pairing multiple devices¹ (optional)

Turn on your speaker and press the pairing button ② for 2 seconds.

Plug your USB receiver into your device and press the pairing button. ⑫

¹Up to a maximum of 3 devices

4 Select your sound and microphone devices

Set your audio settings.

Sound output

- Speaker C027 DONGLE
- Speaker Realtek
- Speaker Sharing Device

Micro

- Micro C027 DONGLE
- Micro Realtek
- Micro Sharing Device

Support et resources : speechi.com/support-micros-visioconference
Email : support@speechi.com