

Lancement rapide de votre écran tactile SpeechiTouch Haute Précision



Référence : ST-XX-AND-UHD-HP-006

1 Allumer l'écran grâce au bouton en dessous à droite de l'écran

2 Palette flottante

3 Sélection du canal

4 Réveil

5 Dessiner avec le(s) doigt(s) ou le(s) stylet(s)

Effacer du revers de la main

6 2 mines différentes (forme, épaisseur et couleur)

7

- 1 Insérer le module WiFi et Bluetooth (en option) en bas de l'écran.
- 2 Connexion à un réseau / création d'un hotspot.

8 Connecter son PC ou son Mac

PC interne en option (voir le manuel OPS)

40 Touch
1 Touch

Support et ressources : www.speechi.net/support/speechitouch
Email : support@speechi.net

Quick Start Guide of your high Precision SpeechiTouch



Reference : ST-XX-AND-UHD-HP-006

1 Switch on (button at the below of the screen)

2 Floating annotation palette

3 Input channel selection

4 Wake up screen

5 Draw with finger(s) or stylus(s)

Delete with backhand

6 2 different nibs (shape, thickness et color)

7

- 1 Plug in the Wifi module (optional) at the bottom of the panel.
- 2 Network connection / Wifi hotspot creation

8 Connect your PC or your Mac

Internal PC optional (see OPS manual)

Support and downloads : www.speechi.net/support/speechitouch
Email : support@speechi.net