

Description

- ① Couper le micro
- ② Allumer / Éteindre
- ③ Volume -
- ④ Bouton d'appairage
- ⑤ Volume +
- ⑥ Indicateur de status
- ⑦ Couper le son
- ⑧ Microphones
- ⑨ Port USB-C
- ⑩ Dongle USB

1 **Charger votre équipement**

Charger votre équipement sur adaptateur secteur USB (non fourni) ou sur un port USB

2 **Appairer un équipement avec sa clé USB**

Allumer votre enceinte et appuyer sur le bouton d'appairage ④ pendant 2 secondes.

Brancher débrancher votre récepteur USB 3x afin de le passer en mode appairage, le voyant doit clignoter rapidement.

3 **Appairer des équipements¹ en cascade (optionnel)**

Allumer vos enceintes et appuyer sur le bouton d'appairage pendant 2 secondes.④

Brancher débrancher votre récepteur USB 3x afin de le passer en mode appairage, le voyant doit clignoter rapidement.

4 **Sélectionner vos périphériques son et micro**

¹Jusqu'à 3 équipements maximum

Support et ressources : speechi.com/support-micros-visioconference
Email : support@speechi.com

Quick start guide of your Wireless speakerphone

speechi

Reference : SPE-AOC023TL

Description

- ① Mute micro
- ② Power button
- ③ Volume down
- ④ Pairing button
- ⑤ Volume up
- ⑥ Status indicator
- ⑦ Mute audio
- ⑧ Microphones
- ⑨ USB-C Port
- ⑩ USB receiver

1 Charge your speakerphone.

Charge your device using a USB power adapter (not provided) or a USB port.

2 Pairing your device with USB Dongle

Turn on your speaker and press the pairing button (④) for 2 seconds.

Plug and unplug your USB receiver 3 times to enter pairing mode; the indicator light should flash rapidly.

3 Pairing multiple devices¹ (optional)

Turn on your speaker and press the pairing button (④) for 2 seconds.

Plug and unplug your USB receiver 3 times to enter pairing mode; the indicator light should flash rapidly.

¹Up to a maximum of 3 devices

4 Select your sound and microphone devices

The screenshot shows the Windows Settings application. The 'Sound' section is highlighted with a red circle. Under 'Sound output', 'Speaker C023TL DONGLE' is selected. Under 'Micro', 'Micro C023 DONGLE' is selected.

Support et resources : speechi.com/support-micros-visioconference
Email : support@speechi.com