

# Lancement rapide de votre écran tactile SpeechiTouch Haute Précision



Référence : ST-XX-UHD-AND-HP3

**1** Allumer l'écran grâce au bouton en dessous à droite de l'écran

**2** Palette flottante

**3** Sélection du canal

**4** Réveil

**5** Dessiner avec le(s) doigt(s) ou le(s) stylet(s)

Effacer du revers de la main

**6** 2 mines différentes (forme, épaisseur et couleur)

**7**

- 1 Insérer le module WiFi et Bluetooth (en option) en bas de l'écran.
- 2 Connexion à un réseau / création d'un hotspot.

**8** Connecter son PC ou son Mac

PC interne en option (voir le manuel OPS)

40 Touch  
1 Touch

**Support et ressources :** [www.speechi.net/support/speechitouch](http://www.speechi.net/support/speechitouch)  
**Email :** [support@speechi.net](mailto:support@speechi.net)

# Quick Start Guide of your high Precision SpeechiTouch



Reference : ST-XX-UHD-AND-HP3

**1** Switch on (button at the below of the screen)

**2** Floating annotation palette

**3** Input channel selection

**4** Wake up screen

**5** Draw with finger(s) or stylus(s)

Delete with backhand

**6** 2 different nibs (shape, thickness et color)

**7**

- 1 Plug in the Wifi module (optional) at the bottom of the panel.
- 2 Network connection / Wifi hotspot creation

**8** Connect your PC or your Mac

Optional Internal PC (see OPS manual)

Windows 40 Touch  
Apple 1 Touch

**Support and downloads :** [www.speechi.net/support/speechitouch](http://www.speechi.net/support/speechitouch)  
**Email :** [support@speechi.net](mailto:support@speechi.net)